



## IMPORTANT

**IMPROVED**— The AccuSalt® now provides more consistent dispensing of salt. As before, the AccuSalt® is used to dispense pre-measured salt on French fries. No guess work required.



### FILLING THE DISPENSER:


- 1) Hold unit by the handle with the cone down.
- 2) Unscrew End Cap. Do not set the Body on the Dispersion Cone
- 3) Fill internal salt Insert Container with salt. Reassemble End Cap onto Body.
- 4) To prepare for use, simply rotate the dispenser and set the AccuSalt® on the End Cap.



**Do Not Set on Cone**

## PROPER USE

### Rotate & Dispense



Reload & storage position

### OPERATING THE DISPENSER:

- 1) Pick up the dispenser by the handle and turn upside down over the fries.
- 2) A pre-measured amount of salt will dispense. No additional salt will dispense until it is recharged.
- 3) To recharge, simply rotate the dispenser back to the original starting position on the End Cap with the dispersion cone facing up.
- 4) The unit will recharge within 2 seconds.

**DO NOT** salt fries over the fryer.  
**DO NOT** shake dispenser.

# Care & Cleaning of AccuSalt®

This dispenser should be washed and completely dry before usage.

## Disassembly for cleaning:

Unscrew End Cap #1, unscrew the Insert Cover #2 Which has a left-handed thread, and slide the Insert Container #3, out of Body #4. Wash the dispenser components, rinse in the sanitizer sink and allow to dry completely overnight before assembling and refilling with salt.

## — AccuSalt® Dispenser (Assembly)



1

End Cap



2

Insert Cover



3

Insert Container



4

Body

